


BK4000 Part List



QUANTUM - Quick Kits			
KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	JAN332-01A	1
4X	DRAG KIT	JAN380-01A	1
2	Retaining Ring		1
3	Drag Washer "D" (3pk)		1
4	Drag Washer "B" (3pk)		1
5X	SPOOL CLICKER & LINE CLIP KIT	JAN303-01A	1
5	Line Clip		1
6	Line Clip Spring		1
7	Line Clip Screw (3pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3pk)		1
12	Clicker Spring		1
10X	SPOOL ASSEMBLY	JAN421-01A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click/Clip Kit		1
16X	SPOOL SUPPORT KIT	JAN315-01A	1
13	Retainer Ring		1
14	Spool Ball Bearing		1
15	Spool Ball Bearing Seal		1
16	Spool Adjust Washer		1
17	Spool Insert		1
18	O-Ring		1
19	Click Gear		1
20	Main Shaft		1
21	Spool Insert Pin		1
35X	BAIL TRIP KIT	JAN319-01A	1
33	Cam		1
34	Kick Lever		1
35	Bail Spring		1
63	Rotor Brake Screw (3pk)		1
64	Trip Bumper		1
90X	HANDLE ASSEMBLY	JAN418-01A	1
90	Handle Arm Sub-Assembly		1
92X	Handle Knob Sub-Assembly		1
92X	HANDLE KNOB KIT	JAN313-01A	1
40	Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3pk)		1
94	Handle Knob Badge		1
95X	DUST CAP ASSEMBLY	JAN373-01A	1

PART LIST -- BK4000							
KEY NO.	DESCRIPTION	PART NUMBER	QTY.	KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	Drag Knob Assembly	JAN332-01A	1	40	Bushing	JAN016-01A	4
2	Retaining Ring	JAN172-01A	1	41	Line Roller	JAN004-01A	1
3	Drag Washer "D" (3 pk)	JAN080-01A-KIT	1	42	Bail Wire Assembly	JAN347-01A	1
4	Drag Washer "B" (3pk)	JAN033-01A-KIT	1	50	Seal	JAN252-01A	1
5	Line Clip	JAN128-01A	1	51	Pinion Ball Bearing Holder Screw (3 pk)	JAN051-01A-KIT	1
6	Line Clip Spring	JAN049-01A	1	54	Pinion Ball Bearing Holder	JAN122-01A	1
7	Line Clip Screw (3 pk)	JAN114-01A-KIT	1	55	Pinion Ball Bearing Holder Seal	JAN263-01A	1
8	Clicker Holder	JAN204-01A	1	56	Pinion Ball Bearing	JAN028-01A	1
9	Clicker	JAN103-01A	1	57	Pinion Ball Bearing Retainer	JAN040-01A	1
10	Spool Sub Assembly -- Use 10X	JAN321-01A	1	58	Pinion Bushing_Top	JAN029-01A	1
11	Clicker Screw (3pk)	JAN246-01A-KIT	1	59	Clutch Unit	JAN463-01A	1
12	Clicker Spring	JAN068-01A	1	60	Pinion	JAN011-01A	1
13	Retainer Ring	JAN038-01A	1	61	Main Shaft Bushing	JAN227-01A	1
14	Spool Ball Bearing	JAN027-01A	1	62	Rotor Brake	JAN145-01A	1
15	Spool Ball Bearing Seal	JAN251-01A	1	63	Rotor Brake Screw (3 pk)	JAN135-01A-KIT	1
16	Spool Adjust Washer	JAN030-01A	1	64	Trip Bumper	JAN119-01A	1
17	Spool Insert	JAN213-01A	1	65	Drive Gear Ball Bearing	JAN058-11A	3
18	O-Ring	HAN266-01A	1	70	Body Sub Assembly	JAN301-01A	1
19	Click Gear	JAN037-01A	1	71	Side Cover Seal	JAN254-01A	1
20	Main Shaft	JAN015-01A	1	72	Drive Gear Ball Bearing Seal	JAN262-01A	2
21	Spool Insert Pin	JAN042-01A	1	73	Drive Gear Ball Bearing Seal Plate	JAN255-01A	2
22	Rotor Cover Screw (3 pk)	JAN077-01A-KIT	3	74	Drive Gear Ball Bearing Screw (3 pk)	JAN220-01A-KIT	2
23	Rotor Nut Retainer	JAN118-01A	1	75	Drive Gear	JAN312-01A	1
24	Rotor Nut Retainer Seal	JAN265-01A	1	76	Drive Gear Adjustment Washer	JAN045-01A	1
25	Rotor Nut Seal	JAN264-01A	1	77	O/S Gear Washer	JAN158-01A	1
26	Rotor Nut	JAN006-01A	1	78	O/S Gear Assembly	JAN353-01A	1
27	Rotor Lock Washer	JAN065-01A	1	79	O/S Gear Screw(3pk)	JAN111-01A-KIT	1
28	Rotor Ring	JAN179-01A	1	80	O/S Slider	JAN025-01A	1
29	Bail Holder/Bail Arm Bushing	JAN259-01A	2	81	Guide Pin	JAN211-01A	1
30	Rotor	JAN009-01A	1	82	Main Shaft Screw(3pk)	JAN100-01A-KIT	1
31	Bail Holder	JAN017-01A	1	83	O/S Slider Plate	JAN084-01A	1
32	Arm Lever Screw (3pk)	JAN225-01A-KIT	1	84	O/S Slider Plate Screw(3pk)	JAN085-01A-KIT	1
33	Cam	JAN031-01A	1	85	Side Cover Sub-Assembly	JAN323-01A	1
34	Kick Lever	JAN019-01A	1	86	Side Cover Screw (3pk)	JAN057-01A-KIT	1
35	Bail Spring	JAN022-01A	1	90	Handle Arm Sub-Assembly	JAN318-01A	1
36	Rotor Cover	JAN087-01A	1	92	Handle Knob	JAN013-01A	1
37	Line Roller Screw(3pk)	JAN108-01A-KIT	1	93	Handle Knob Screw (3pk)	JAN085-01A-KIT	1
38	Arm Lever	JAN007-01A	1	94	Handle Knob Badge	JAN169-01A	1
39	Line Roller Washer	JAN102-01A	1	95X	Dust Cap Assembly	JAN373-01A	1