


QUANTUM
STRIVE SV5000 Part List



QUANTUM - Quick Kits			
KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	DAN332-01A	1
4X	DRAG KIT	DAN380-01A	1
2	Retaining Ring		1
3	Drag Washer "D" (3 pk)		1
4	Drag Washer "B" (3 pk)		1
5X	SPOOL CLICKER&LINE CLIP KIT	DAN303-01A	1
5	Line Clip Spring		1
6	Line Clip		1
7	Screw (3 pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3 pk)		1
12	Clicker Spring		1
100	Clicker Spring Washer		1
10X	SPOOL ASSEMBLY	DAN421-01A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click&Clip Kit		1
16X	SPOOL SUPPORT KIT	DAN415-01A	1
15	Spool Metal Seal		1
16	Spool Adjust Washer		1
20	Main Shaft Assembly		1
35X	BAIL TRIP KIT	DAN319-01A	1
33	Cam		1
34	Kick Lever		1
35	Coil Spring		1
64	Trip Bumper		1
101	Trip Bumper Screw (3 pk)		1
90X	HANDLE ASSEMBLY	DAN418-01A	1
90	Handle Arm Assembly		1
92X	Handle Knob Assembly		1
92X	HANDLE KNOB KIT	CAN313-01A	1
91	Handle Knob Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3 pk)		1
94	Handle Knob Cap		1
95X	DUST CAP ASSEMBLY	DAN373-01A	1

PART LIST -- SV5000							
KEY NO.	DESCRIPTION	PART NUMBER	QTY.	KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	Drag Knob Assembly	DAN332-01A	1	50	Seal	CAN252-01A	1
2	Retaining Ring	EAK172-01A	1	53	Pinion Ball Bearing Holder Screw (3 pk)	EAK051-01A-KIT	1
3	Drag Washer "D" (3 pk)	DAN080-01A-KIT	1	54	Pinion Ball Bearing Holder	DAN122-01A	1
4	Drag Washer "B" (3 pk)	DAN033-01A-KIT	1	55	Pinion Ball Bearing Holder Seal	EAN263-01A	1
5	Line Clip	EAK128-01A	1	56	Pinion Ball Bearing	CP058-05A	4
6	Line Clip Spring	EAK049-01A	1	57	Pinion Ball Bearing Retainer	EAK040-01A	1
7	Screw (3 pk)	EAK114-01A-KIT	1	58	Pinion Bushing_TOP	DAN028-01A	1
8	Clicker Holder	EAK204-01A	1	59	Clutch Unit	EAK463-01A	1
9	Clicker	EAK103-01A	1	60	Pinion	DAN011-01A	1
10	Spool Sub Assembly--Use 10X	DAN321-01A	1	61	Bushing - Body Anchor	DAN227-01A	1
11	Clicker Screw (3 pk)	EAK246-01A-KIT	1	62	Rotor Brake	DAN145-01A	1
12	Clicker Spring	DAK068-01A	1	63	Rotor Brake Screw (3 pk)	EAK135-01A-KIT	1
15	Spool Metal Seal	DAN251-01A	1	64	Trip bumper	DAN119-01A	1
16	Spool Adjust Washer	EAK030-01A	1	70	Body Assembly	DAN301-01A	1
20	Main Shaft Assembly	DAN315-01A	1	71	Side Cover Seal	DAN254-01A	1
22	Rotor Nut Retainer Screw (3 pk)	EAK094-01A-KIT	1	72	Drive Gear Ball Bearing Seal	EAN262-01A	2
23	Rotor Nut Retainer	EAK118-01A	1	73	Drive Gear Ball Bearing Seal Plate	EAK255-01A	2
24	Rotor Nut Retainer Seal	DAN264-01A	1	74	Drive Gear Ball Bearing Screw (3 pk)	EAK220-01A-KIT	2
25	Rotor Nut Seal	DAN265-01A	1	75	Drive Gear	DAN012-01A	1
26	Rotor Nut	EAK006-01A	1	77	O/S Gear Washer	DAN158-01A	1
29	Bushing	BAN259-01A	2	78	O/S Gear	DAN053-02A	1
30	Rotor	DAN009-01A	1	79	O/S Gear Screw (3 pk)	EAK111-01A-KIT	1
32	Arm Lever Screw (3 pk)	CAN225-01A-KIT	1	80	Slider	DAN025-01A	1
33	Cam	DAN031-01A	1	81	Guide Pin	DAN211-01A	1
34	Kick Lever	DAN019-01A	1	82	Main Shaft Screw (3 pk)	EAK100-01A-KIT	1
35	Coil Spring	DAN022-01A	1	83	Slider Plate	EAK084-01A	1
36	Rotor Cover	DAN087-01A	1	84	Slider Plate Screw (3 pk)	EAK085-01A-KIT	1
37	Line Roller Screw (3 pk)	CAN108-01A-KIT	1	85	Side Cover Assembly	DAN323-01A	1
38	Arm Lever	DAN007-01A	1	86B	Side Cover Screw (3 pk)	CAN057-01A-KIT	1
39	Line Roller Collar	EAK102-01A	1	90	Handle Arm Assembly	DAN318-01A	1
40	Line Roller Bushing	EAK106-01A	2	91	Handle Knob Bushing	CAN027-01A	2
41	Line Roller	EAN004-01A	1	92	Handle Knob	CAN013-01A	1
42	Bail Wire Assembly	DAN347-01A	1	93	Handle Knob Screw (3 pk)	CAN123-01A-KIT	1
43	Line Roller Washer_shorter	EAK102-51A	1	94	Handle Knob Cap	CAN169-01A	1
45	Line Roller Washer_longer	EAK102-52A	1	95X	Dust Cap Assembly	DAN373-01A	1
47	Rotor Cover Screw (3 pk)	DAN077-01A-KIT	1	100	Clicker Spring Washer	EAK167-01A	1
48	Rotor Adjuster Washer	DAN065-01A	1	101	Trip bumper screw (3 pk)	EAK123-01A-KIT	1