


QUANTUM
MERIT™ MT4000 Part List



QUANTUM - Quick Kits			
KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	CAN332-01A	1
4X	DRAG KIT	CAN380-01A	1
2	Retaining Ring		1
3	Metal D Washer (3 pk)		1
4	Keyed Friction Washer (3 pk)		1
5X	SPOOL CLICKER&LINE CLIP KIT	JAS303-01A	1
7	Screw (3 pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3 pk)		1
12	Clicker Spring		1
100	Clicker Spring Washer		1
10X	SPOOL ASSEMBLY	LAS421-01A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click&Clip Kit		1
16X	SPOOL SUPPORT KIT	LAS415-01A	1
15	Spool Metal Seal		1
16	Spool Adjust Washer		1
20	Main Shaft Assembly		1
35X	BAIL TRIP KIT	LAS319-01A	1
33	Cam		1
34	Kick Lever		1
35	Coil Spring		1
90X	HANDLE ASSEMBLY	LAS418-01A	1
90	Handle Arm Assembly		1
92X	Handle Knob Assembly		1
92X	HANDLE KNOB KIT	CAN313-01A	1
91	Handle Knob Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3 pk)		1
94	Handle Knob Cap		1
95X	DUST CAP ASSEMBLY	CAN373-01A	1

PART LIST -- MT4000							
KEY NO.	DESCRIPTION	PART NUMBER	QTY.	KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	Drag Knob Assembly	CAN332-01A	1	54	Pinion Ball Bearing Holder	CAN122-01A	1
2	Retaining Ring	EAK172-01A	1	55	Pinion Ball Bearing Holder Seal	CAN263-01A	1
3	Metal D Washer (3 pk)	AAN080-01A-KIT	1	56	Pinion Ball Bearing	TW058-11A	3
4	Keyed Friction Washer (3 pk)	AAN033-01A-KIT	1	57	Pinion Ball Bearing Retainer	CAK040-01A	1
7	Screw (3 pk)	EAK114-01A-KIT	1	58	Pinion Bushing_Top	CAN028-01A	1
8	Clicker Holder	EAK204-01A	1	59	Clutch Unit	CAK463-01A	1
9	Clicker	EAK103-01A	1	60	Pinion	CAN011-01A	1
10	Spool Sub Assembly --Use 10X			61	Bushing - Body Anchor	CAN227-01A	1
11	Clicker Screw (3 pk)	EAK246-01A-KIT	1	62	Rotor Brake	CAN145-01A	1
12	Clicker Spring	DAK068-01A	1	63	Rotor Brake Screw (3 pk)	EAK135-01A-KIT	1
15	Spool Metal Seal	CAN251-01A	1	70	Body Assembly	LAS301-01A	1
16	Spool Adjust Washer	CAK030-01A	1	71	Side Cover Seal	LAS254-01A	1
20	Main Shaft Assembly	LAS315-01A	1	72	Drive Gear Ball Bearing Seal	AAN262-01A	2
22	Rotor Nut Retainer Screw (3 pk)	EAK094-01A-KIT	1	73	Drive Gear Ball Bearing Seal Plate	JAS255-01A	2
23	Rotor Nut Retainer	EAK118-01A	1	74	Side Cover Ball Bearing Screw (3 pk)	EAK220-01A-KIT	1
24	Rotor Nut Retainer Seal	DAN264-01A	1	75	Drive Gear	LAS012-01A	1
25	Rotor Nut Seal	CAN265-01A	1	76	Drive Gear Ball Bearing Screw (3 pk)	JAS220-01A-KIT	1
26	Rotor Nut	CAN006-01A	1	77	O/S Gear Washer	JAS158-01A	1
29	Bushing	BAN259-01A	2	78	O/S Gear	LAS053-01A	1
30	Rotor	CAN009-10A	1	79	O/S Gear Screw (3 pk)	JAS111-01A-KIT	1
32	Arm Lever Screw (3 pk)	CAN225-01A-KIT	1	80	Slider	CAN025-01A	1
33	Cam	CAN031-01A	1	81	Guide Pin	CAK211-01A	1
34	Kick Lever	CAN019-01A	1	82	Main Shaft Screw (3 pk)	CAK100-01A-KIT	1
35	Coil Spring	CAN022-01A	1	83	Slider Plate	LAS084-01A	1
36	Rotor Cover	CAN087-10A	1	84	Slider Plate Screw (3 pk)	JAS085-01A-KIT	1
37	Line Roller Screw (3 pk)	CAN108-01A-KIT	1	85	Side Cover Assembly	LAS323-01A	1
38	Arm Lever	BAN007-10A	1	86A	Side Cover Screw1 (3 pk)	LAS163-01A-KIT	1
39	Line Roller Collar	LAS102-01A	1	86B	Side Cover Screw2 (3 pk)	LAS057-01A-KIT	1
40	Line Roller Bushing	EAK106-01A	2	86C	Side Cover Screw3 (3 pk)	JAS168-01A-KIT	1
41	Line Roller	CAN004-01A	1	87	Drive Gear Seal	JAS265-01A	1
42	Bail Wire Assembly	LAS347-01A	1	88	Pinion Ball Bearing	UK028-01A	1
43	Line Roller Washer_shorter	EAK102-51A	1	90	Handle Arm Assembly	LAS318-01A	1
45	Line Roller Washer_longer	EAK102-52A	1	91	Handle Knob Bushing	CAN027-01A	2
47	Rotor Cover Screw (3 pk)	CAN077-01A-KIT	1	92	Handle Knob	CAN013-01A	1
48A	Rotor Adjust Washer	CAN065-01A	1	93	Handle Knob Screw (3 pk)	CAN123-01A-KIT	1
48B	Pinion Washer	AAN065-01A	1	94	Handle Knob Cap	CAN169-01A	1
50	Seal	CAN252-01A	1	95X	Dust Cap Assembly	CAN373-01A	1
53	Pinion Ball Bearing Holder Screw (3 pk)	JAS051-01A-KIT	1	100	Clicker Spring Washer	EAK167-01A	1
				110	Rear Cap	LAS250-01A	1