


QUANTUM
MERIT™ MT6000 Part List



QUANTUM - Quick Kits			
KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	EAN332-01A	1
4X	DRAG KIT	DAN380-01A	1
2	Retaining Ring		1
3	Metal D Washer (3 pk)		1
4	Keyed Friction Washer (3 pk)		1
5X	SPOOL CLICKER&LINE CLIP KIT	NAS303-01A	1
7	Screw (3 pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3 pk)		1
12	Clicker Spring		1
100	Clicker Spring Washer		1
10X	SPOOL ASSEMBLY	NAS421-01A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click&Clip Kit		1
16X	SPOOL SUPPORT KIT	EAN415-01A	1
15	Spool Metal Seal		1
16	Spool Adjust Washer		1
20	Main Shaft Assembly		1
35X	BAIL TRIP KIT	NAS319-01A	1
33	Cam		1
34	Kick Lever		1
35	Coil Spring		1
90X	HANDLE ASSEMBLY	NAS418-01A	1
90	Handle Arm Assembly		1
92X	Handle Knob Assembly		1
92X	HANDLE KNOB KIT	EAN313-01A	1
91	Handle Knob Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3 pk)		1
94	Handle Knob Cap		1
95X	DUST CAP ASSEMBLY	DAN373-01A	1

PART LIST -- MT6000				
KEY NO.	DESCRIPTION	PART NUMBER	QTY.	
1X	Drag Knob Assembly	EAN332-01A	1	
2	Retaining Ring	EAK172-01A	1	
3	Metal D Washer (3 pk)	DAN080-01A-KIT	1	
4	Keyed Friction Washer (3 pk)	DAN033-01A-KIT	1	
7	Screw (3 pk)	EAK114-01A-KIT	1	
8	Clicker Holder	EAK204-01A	1	
9	Clicker	EAK103-01A	1	
10	Spool Sub Assembly--Use 10X	-	-	
11	Clicker Screw (3 pk)	EAK246-01A-KIT	1	
12	Clicker Spring	EAK068-01A	1	
15	Spool Metal Seal	DAN251-01A	1	
16	Spool Adjust Washer	EAK030-01A	1	
20	Main Shaft Assembly	EAN315-01A	1	
22	Rotor Nut Retainer Screw (3 pk)	EAK094-01A-KIT	1	
23	Rotor Nut Retainer	EAK118-01A	1	
24	Rotor Nut Retainer Seal	DAN264-01A	2	
25	Rotor Nut Seal	DAN265-01A	1	
26	Rotor Nut	EAK006-01A	1	
29	Bushing	BAN259-01A	2	
30	Rotor	EAN009-10A	1	
32	Arm Lever Screw (3 pk)	CAN225-01A-KIT	1	
33	Cam	DAN031-01A	1	
34	Kick Lever	EAN019-01A	1	
35	Coil Spring	DAN022-01A	1	
36	Rotor Cover	EAN087-10A	1	
37	Line Roller Screw (3 pk)	CAN108-01A-KIT	1	
38	Arm Lever	EAN007-10A	1	
39	Line Roller Collar	EAK102-01A	1	
40	Line Roller Bushing	EAK106-01A	2	
41	Line Roller	EAN004-01A	1	
42	Bail Wire Assembly	NAS347-01A	1	
43	Line Roller Washer_shorter	EAK102-51A	1	
45	Line Roller Washer_longer	EAK102-52A	1	
47	Rotor Cover Screw (3 pk)	DAN077-01A-KIT	1	
49	Silent Ring	EAK059-01A	1	
50	Seal	EAN252-01A	1	
51	Silent Ring Sleeve	EAK078-01A	1	
52	Silent Spring	EAK069-01A	1	
53	Pinion Ball Bearing Holder Screw (3 pk)	MAS051-01A-KIT	1	
54	Pinion Ball Bearing Holder	EAK122-01A	1	
55	Pinion Ball Bearing Holder Seal	EAN263-01A	1	
56	Pinion Ball Bearing	CP058-05A	4	
57	Pinion Ball Bearing Retainer	EAK040-01A	1	
58	Pinion Bushing_Top	DAN028-01A	1	
59	Clutch Unit	EAK463-01A	1	
60	Pinion	EAN011-01A	1	
61	Bushing - Body Anchor	DAN227-01A	1	
62	Rotor Brake	EAK145-01A	1	
63	Rotor Brake Screw (3 pk)	EAK135-01A-KIT	1	
66	Anti-Reverse Pawl Spring Space	EAK091-01A	1	
67	Anti-Reverse Pawl	EAK090-01A	1	
68	Anti-Reverse Pawl Spring	EAK089-01A	1	
69	E-clip	QW120-01A	1	
70	Body Assembly	NAS301-01A	1	
71	Side Cover Seal	NAS254-01A	1	
72	Drive Gear Ball Bearing Seal	EAN262-01A	2	
73	Drive Gear Ball Bearing Seal Plate	MAS255-01A	2	
74	Side Cover Ball Bearing Screw (3 pk)	EAK220-01A-KIT	1	
75	Drive Gear	NAS012-01A	1	
76	Drive Gear Ball Bearing Screw (3 pk)	JAS220-01A-KIT	1	
77	O/S Gear Washer	EAK158-01A	1	
78	O/S Gear	NAS053-01A	1	
79	O/S Gear Screw (3 pk)	MAS111-01A-KIT	1	
80	Slider	EAN025-01A	1	
81	Guide Pin	EAN211-01A	1	
82	Main Shaft Screw (3 pk)	EAK100-01A-KIT	1	
83	Slider Plate	MAS084-01A	1	
84	Slider Plate Screw (3 pk)	JAS085-01A-KIT	1	
85	Side Cover Assembly	NAS323-01A	1	
86A	Side Cover Screw1 (3 pk)	MAS163-01A-KIT	1	
86B	Side Cover Screw2 (3 pk)	MAS057-01A-KIT	1	
87	Drive Gear Seal	EAN265-01A	1	
90	Handle Arm Assembly	NAS318-01A	1	
91	Handle Knob Bushing	EAN027-01A	2	
92	Handle Knob	EAN013-01A	1	
93	Handle Knob Screw (3 pk)	CAN123-01A-KIT	1	
94	Handle Knob Cap	EAN169-01A	1	
95X	Dust Cap Assembly	DAN373-01A	1	
100	Clicker Spring Washer	EAK167-01A	1	
110	Rear Cap	NAS250-01A	1	
111	Rear Cap Screw (3 pk)	CAN077-01A-KIT	1	