



QUANTUM - Quick Kits

KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	KAN332-01A	1
4X	DRAG KIT	KAN380-01A	1
2	Retaining Ring		1
3	Metal D washer (3 pk)		1
4	Keyed Friction Washer (3pk)		1
5X	SPOOL CLICKER & LINE CLIP KIT	KAN303-01A	1
5	Line Clip		1
6	Line Clip Spring		1
7	Line Clip Screw (3 pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3pk)		1
12	Clicker Spring		1
10X	SPOOL ASSEMBLY	KAN421-01A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click/Clip Kit		1
16X	SPOOL SUPPORT KIT	KAN315-01A	1
13	Retainer Ring		1
14	Spool Ball Bearing		1
15	Spool Ball Bearing Seal		1
16	Spool Adjust Washer		1
17	Spool Insert		1
18	O-Ring		1
19	Click Gear		1
20	Main Shaft		1
21	Spool Insert Pin		1
35X	BAIL TRIP KIT	KAN319-01A	1
33	Cam		1
34	Kick Lever		1
35	Bail Spring		1
63	Rotor Brake Screw (3 pk)		1
64	Trip Bumper		1
90X	HANDLE ASSEMBLY	KAN418-01A	1
90	Handle Arm Sub-Assembly		1
92X	Handle Knob Sub-Assembly		1
92X	HANDLE KNOB KIT	JAN313-01A	1
91	Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3pk)		1
94	Handle Knob Badge		1
95X	DUST CAP ASSEMBLY	KAN373-01A	1

PART LIST -- BK5000

KEY NO.	DESCRIPTION	PART NUMBER	QTY.	KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	Drag Knob Assembly	KAN332-01A	1	41	Line Roller	KAN004-01A	1
2	Retaining Ring	KAN172-01A	1	42	Bail Wire Assembly	KAN347-01A	1
3	Metal D washer (3 pk)	KAN080-01A-KIT	1	50	Seal	KAN252-01A	1
4	Keyed Friction Washer (3pk)	KAN033-01A-KIT	1	53	Pinion Ball Bearing Holder Screw (3 pk)	JAN051-01A-KIT	1
5	Line Clip	KAN128-01A	1	54	Pinion Ball Bearing Holder	KAN122-01A	1
6	Line Clip Spring	KAN049-01A	1	55	Pinion Ball Bearing Holder Seal	KAN263-01A	1
7	Line Clip Screw (3 pk)	JAN114-01A-KIT	1	56	Pinion Ball Bearing	KAN028-01A	4
8	Clicker Holder	JAN204-01A	1	57	Pinion Ball Bearing Retainer	KAN040-01A	1
9	Clicker	JAN103-01A	1	58	Pinion Bushing_Top	KAN029-01A	1
10	Spool Sub Assembly -- Use 10X	KAN321-01A	1	59	Clutch Unit	KAN463-01A	1
11	Clicker Screw (3pk)	JAN246-01A-KIT	1	60	Pinion	KAN011-01A	1
12	Clicker Spring	JAN068-01A	1	61	Main Shaft Bushing	KAN227-01A	1
13	Retainer Ring	KAN038-01A	1	62	Rotor Brake	KAN145-01A	1
14	Spool Ball Bearing	KAN027-01A	1	63	Rotor Brake Screw (3 pk)	KAN135-01A-KIT	1
15	Spool Ball Bearing Seal	KAN251-01A	1	64	Trip Bumper	KAN119-01A	1
16	Spool Adjust Washer	KAN030-01A	1	70	Body Sub Assembly	KAN301-01A	1
17	Spool Insert	KAN213-01A	1	71	Side Cover Seal	KAN254-01A	1
18	O-Ring	KAN266-01A	1	72	Drive Gear Ball Bearing Seal	KAN262-01A	2
19	Click Gear	KAN037-01A	1	73	Drive Gear Ball Bearing Seal Plate	KAN255-01A	2
20	Main Shaft	KAN015-01A	1	74	Drive Gear Ball Bearing Screw (3 pk)	JAN220-01A-KIT	2
21	Spool Insert Pin	KAN042-01A	1	75	Drive Gear	KAN312-01A	1
22	Rotor Cover Screw (3 pk)	JAN077-01A-KIT	3	76	Drive Gear Adjustment Washer	KAN045-01A	1
23	Rotor Nut Retainer	JAN118-01A	1	77	O/S Gear Washer	KAN158-01A	1
24	Rotor Nut Retainer Seal	JAN265-01A	1	78	O/S Gear Assembly	KAN353-01A	1
25	Rotor Nut Seal	KAN264-01A	1	79	O/S Gear Screw(3pk)	KAN111-01A-KIT	1
26	Rotor Nut	KAN006-01A	1	80	O/S Slider	KAN025-01A	1
27	Rotor Lock Washer	KAN065-01A	1	81	Guide Pin	KAN211-01A	1
28	Rotor Ring	KAN179-01A	1	82	Main Shaft Screw(3pk)	KAN100-01A-KIT	1
29	Bail Holder/Bail Arm Bushing	KAN259-01A	2	83	O/S Slider Plate	KAN084-01A	1
30	Rotor	KAN009-01A	1	84	O/S Slider Plate Screw(3pk)	JAN085-01A-KIT	1
31	Bail Holder	KAN017-01A	1	85	Side Cover Sub-Assembly	KAN323-01A	1
32	Arm Lever Screw (3pk)	KAN225-01A-KIT	1	86A	Side Cover Screw A (3pk)	LAN057-01A-KIT	1
33	Cam	KAN031-01A	1	86B	Side Cover Screw B (3pk)	KAN057-01A-KIT	1
34	Kick Lever	KAN019-01A	1	90	Handle Arm Sub-Assembly	KAN318-01A	1
35	Bail Spring	KAN022-01A	1	91	Bushing	JAN016-01A	2
36	Rotor Cover	KAN087-01A	1	92	Handle Knob	JAN013-01A	1
37	Line Roller Screw(3pk)	KAN108-01A-KIT	1	93	Handle Knob Screw (3pk)	JAN085-01A-KIT	1
38	Arm Lever	KAN007-01A	1	94	Handle Knob Badge	JAN169-01A	1
39	Line Roller Washer	KAN102-01A	1	95X	Dust Cap Assembly	KAN373-01A	1
40	Bushing	KAN016-01A	2				