



QUANTUM - Quick Kits			
KEY NO.	DESCRIPTION	PART NUMBER	QTY.
1X	DRAG KNOB ASSEMBLY	MAN332-01A	1
4X	DRAG KIT	MAN380-02A	1
2	Retaining Ring		1
3	Metal D washer (3 pk)		1
4	Keyed Friction Washer (3pk)		1
5X	SPOOL CLICKER KIT	MAN303-01A	1
7	Line Clip Screw (3 pk)		1
8	Clicker Holder		1
9	Clicker		1
11	Clicker Screw (3pk)		1
12	Clicker Spring		1
10X	SPOOL ASSEMBLY	MAN421-02A	1
4X	Drag Kit		1
10	Spool Sub Assembly		1
5X	Spool Click/Clip Kit		1
16X	SPOOL SUPPORT KIT	MAN315-01A	1
13	Retainer Ring		1
14	Spool Ball Bearing		1
15	Spool Ball Bearing Seal		1
16	Spool Adjust Washer		1
17	Spool Insert		1
18	O-Ring		1
19	Click Gear		1
20	Main Shaft		1
21	Spool Insert Pin		1
35X	BAIL TRIP KIT	MAN319-01A	1
33	Cam		1
34	Kick Lever		1
35	Bail Spring		1
90X	HANDLE ASSEMBLY	MAN418-01A	1
90	Handle Arm Sub-Assembly		1
92X	Handle Knob Sub-Assembly		1
92X	HANDLE KNOB KIT	LAN313-01A	1
40	Bushing		2
92	Handle Knob		1
93	Handle Knob Screw (3pk)		1
94	Handle Knob Badge		1
95X	DUST CAP ASSEMBLY	MAN373-01A	1

PART LIST -- BK8000											
KEY NO.	DESCRIPTION	PART NUMBER	QTY.	KEY NO.	DESCRIPTION	PART NUMBER	QTY.				
1X	Drag Knob Assembly	MAN332-01A	1	51	Silent Ring Sleeve	MAN078-01A	1				
2	Retaining Ring	KAN172-01A	1	52	Coil Spring	LAN069-01A	1				
3	Metal D washer (3 pk)	MAN080-01A-KIT	1	53	Pinion Ball Bearing Holder Screw (3 pk)	MAN051-01A-KIT	1				
4	Keyed Friction Washer (3pk)	MAN033-02A-KIT	1	54	Pinion Ball Bearing Holder	MAN122-01A	1				
7	Line Clip Screw (3 pk)	JAN114-01A-KIT	1	55	Pinion Ball Bearing Holder Seal	MAN263-01A	1				
8	Clicker Holder	JAN204-01A	1	56	Pinion Ball Bearing	MAN028-01A	4				
9	Clicker	JAN103-01A	1	57	Pinion Ball Bearing Retainer	MAN040-01A	1				
10	Spool Sub Assembly -- Use 10X	MAN321-02A	1	58	Pinion Bushing_Top	MAN029-01A	1				
11	Clicker Screw (3pk)	JAN246-01A-KIT	1	59	Clutch Unit	MAN463-01A	1				
12	Clicker Spring	JAN068-01A	1	60	Pinion	MAN011-01A	1				
13	Retainer Ring	KAN038-01A	1	61	Main Shaft Bushing	MAN227-01A	1				
14	Spool Ball Bearing	KAN027-01A	1	62	Rotor Brake	MAN145-01A	1				
15	Spool Ball Bearing Seal	KAN251-01A	1	63	Rotor Brake Screw (3 pk)	KAN135-01A-KIT	1				
16	Spool Adjust Washer	KAN030-01A	1	66	Anti-Reverse Actuator Shoulder Post	MAN091-01A	1				
17	Spool Insert	MAN213-01A	1	67	Anti-Reverse Actuator	MAN090-01A	1				
18	O-Ring	KAN266-01A	1	68	Anti-Reverse Actuator Spring	MAN089-01A	1				
19	Click Gear	KAN037-01A	1	69	E-Clip	MAN120-01A	1				
20	Main Shaft	MAN015-01A	1	70	Body Sub Assembly	MAN301-01A	1				
21	Spool Insert Pin	KAN042-01A	1	71	Side Cover Seal	MAN254-01A	1				
22	Rotor Cover Screw (3 pk)	LAN077-01A-KIT	3	72	Drive Gear Ball Bearing Seal	MAN262-01A	2				
23	Rotor Nut Retainer	MAN118-01A	1	73	Drive Gear Ball Bearing Seal Plate	MAN255-01A	2				
24	Seal Ring	MAN265-01A	2	74	Drive Gear Ball Bearing Screw (3 pk)	JAN220-01A-KIT	2				
25	Rotor Nut Seal	MAN264-01A	1	75	Drive Gear	MAN312-01A	1				
26	Rotor Nut	MAN006-01A	1	76	Drive Gear Adjustment Washer	MAN045-01A	1				
28	Rotor Ring	MAN179-01A	1	77	O/S Gear Washer	MAN158-01A	1				
30	Rotor	MAN009-01A	1	78	O/S Gear Assembly	MAN353-01A	1				
31	Bail Holder	MAN017-01A	1	79	O/S Gear Screw(3pk)	KAN111-01A-KIT	1				
32	Arm Lever Screw (3pk)	LAN225-01A-KIT	1	80	O/S Slider	MAN025-01A	1				
33	Cam	KAN031-01A	1	81	Guide Pin	MAN211-01A	1				
34	Kick Lever	MAN019-01A	1	82A	Main Shaft Screw(3pk)	KAN100-01A-KIT	1				
35	Bail Spring	KAN022-01A	1	82B	Main Shaft Screw B (3pk)	MAN100-01A-KIT	1				
36	Rotor Cover	MAN087-01A	1	83	O/S Slider Plate	MAN084-01A	1				
37	Line Roller Screw(3pk)	KAN108-01A-KIT	1	84	O/S Slider Plate Screw(3pk)	JAN085-01A-KIT	1				
38	Arm Lever	MAN007-01A	1	85	Side Cover Sub-Assembly	MAN323-01A	1				
39	Line Roller Washer	MAN102-01A	1	86	Side Cover Screw (3pk)	KAN057-01A-KIT	2				
40	Bushing	KAN016-01A	4	90	Handle Arm Sub-Assembly	MAN318-01A	1				
41	Line Roller	KAN004-01A	1	92	Handle Knob	LAN013-01A	1				
42	Bail Wire Assembly	MAN347-01A	1	93	Handle Knob Screw (3pk)	JAN085-01A-KIT	1				
49	Silent Ring	MAN059-01A	1	94	Handle Knob Badge	LAN169-01A	1				
50	Seal	LAN252-01A	1	95X	Dust Cap Assembly	MAN373-01A	1				