


**QUANTUM**  
MERIT™ MT5000 Part List



| QUANTUM - Quick Kits |                              |             |      |
|----------------------|------------------------------|-------------|------|
| KEY NO.              | DESCRIPTION                  | PART NUMBER | QTY. |
| 1X                   | DRAG KNOB ASSEMBLY           | DAN332-01A  | 1    |
| 4X                   | DRAG KIT                     | DAN380-01A  | 1    |
| 2                    | Retaining Ring               |             | 1    |
| 3                    | Metal D Washer (3 pk)        |             | 1    |
| 4                    | Keyed Friction Washer (3 pk) |             | 1    |
| 5X                   | SPOOL CLICKER&LINE CLIP KIT  | JAS303-01A  | 1    |
| 7                    | Screw (3 pk)                 |             | 1    |
| 8                    | Clicker Holder               |             | 1    |
| 9                    | Clicker                      |             | 1    |
| 11                   | Clicker Screw (3 pk)         |             | 1    |
| 12                   | Clicker Spring               |             | 1    |
| 100                  | Clicker Spring Washer        |             | 1    |
| 10X                  | SPOOL ASSEMBLY               | MAS421-01A  | 1    |
| 4X                   | Drag Kit                     |             | 1    |
| 10                   | Spool Sub Assembly           |             | 1    |
| 5X                   | Spool Click&Clip Kit         |             | 1    |
| 16X                  | SPOOL SUPPORT KIT            | DAN415-01A  | 1    |
| 15                   | Spool Metal Seal             |             | 1    |
| 16                   | Spool Adjust Washer          |             | 1    |
| 20                   | Main Shaft Assembly          |             | 1    |
| 35X                  | BAIL TRIP KIT                | MAS319-01A  | 1    |
| 33                   | Cam                          |             | 1    |
| 34                   | Kick Lever                   |             | 1    |
| 35                   | Coil Spring                  |             | 1    |
| 90X                  | HANDLE ASSEMBLY              | MAS418-01A  | 1    |
| 90                   | Handle Arm Assembly          |             | 1    |
| 92X                  | Handle Knob Assembly         |             | 1    |
| 92X                  | HANDLE KNOB KIT              | CAN313-01A  | 1    |
| 91                   | Handle Knob Bushing          |             | 2    |
| 92                   | Handle Knob                  |             | 1    |
| 93                   | Handle Knob Screw (3 pk)     |             | 1    |
| 94                   | Handle Knob Cap              |             | 1    |
| 95X                  | DUST CAP ASSEMBLY            | DAN373-01A  | 1    |

| PART LIST -- MT5000 |                                         |                |      |         |                                      |                |      |
|---------------------|-----------------------------------------|----------------|------|---------|--------------------------------------|----------------|------|
| KEY NO.             | DESCRIPTION                             | PART NUMBER    | QTY. | KEY NO. | DESCRIPTION                          | PART NUMBER    | QTY. |
| 1X                  | Drag Knob Assembly                      | DAN332-01A     | 1    | 54      | Pinion Ball Bearing Holder           | DAN122-01A     | 1    |
| 2                   | Retaining Ring                          | EAK172-01A     | 1    | 55      | Pinion Ball Bearing Holder Seal      | EAN263-01A     | 1    |
| 3                   | Metal D Washer (3 pk)                   | DAN080-01A-KIT | 1    | 56      | Pinion Ball Bearing                  | CP058-05A      | 4    |
| 4                   | Keyed Friction Washer (3 pk)            | DAN033-01A-KIT | 1    | 57      | Pinion Ball Bearing Retainer         | EAK040-01A     | 1    |
| 7                   | Screw (3 pk)                            | EAK114-01A-KIT | 1    | 58      | Pinion Bushing_TOP                   | DAN028-01A     | 1    |
| 8                   | Clicker Holder                          | EAK204-01A     | 1    | 59      | Clutch Unit                          | EAK463-01A     | 1    |
| 9                   | Clicker                                 | EAK103-01A     | 1    | 60      | Pinion                               | DAN011-01A     | 1    |
| 10                  | Spool Sub Assembly--Use 10X             |                |      | 61      | Bushing - Body Anchor                | DAN227-01A     | 1    |
| 11                  | Clicker Screw (3 pk)                    | EAK246-01A-KIT | 1    | 62      | Rotor Brake                          | DAN145-01A     | 1    |
| 12                  | Clicker Spring                          | EAK068-01A     | 1    | 63      | Rotor Brake Screw (3 pk)             | EAK135-01A-KIT | 1    |
| 15                  | Spool Metal Seal                        | DAN251-01A     | 1    | 70      | Body Assembly                        | MAS301-01A     | 1    |
| 16                  | Spool Adjust Washer                     | EAK030-01A     | 1    | 71      | Side Cover Seal                      | MAS254-01A     | 1    |
| 20                  | Main Shaft Assembly                     | DAN315-01A     | 1    | 72      | Drive Gear Ball Bearing Seal         | EAN262-01A     | 2    |
| 22                  | Rotor Nut Retainer Screw (3 pk)         | EAK094-01A-KIT | 1    | 73      | Drive Gear Ball Bearing Seal Plate   | MAS255-01A     | 2    |
| 23                  | Rotor Nut Retainer                      | EAK118-01A     | 1    | 74      | Side Cover Ball Bearing Screw (3 pk) | EAK220-01A-KIT | 1    |
| 24                  | Rotor Nut Retainer Seal                 | DAN264-01A     | 1    | 75      | Drive Gear                           | MAS012-01A     | 1    |
| 25                  | Rotor Nut Seal                          | DAN265-01A     | 1    | 76      | Drive Gear Ball Bearing Screw (3 pk) | JAS220-01A-KIT | 1    |
| 26                  | Rotor Nut                               | EAK006-01A     | 1    | 77      | O/S Gear Washer                      | MAS158-01A     | 1    |
| 29                  | Bushing                                 | BAN259-01A     | 2    | 78      | O/S Gear                             | MAS053-01A     | 1    |
| 30                  | Rotor                                   | DAN009-10A     | 1    | 79      | O/S Gear Screw (3 pk)                | MAS111-01A-KIT | 1    |
| 32                  | Arm Lever Screw (3 pk)                  | CAN225-01A-KIT | 1    | 80      | Slider                               | DAN025-01A     | 1    |
| 33                  | Cam                                     | DAN031-01A     | 1    | 81      | Guide Pin                            | DAN211-01A     | 1    |
| 34                  | Kick Lever                              | DAN019-01A     | 1    | 82      | Main Shaft Screw (3 pk)              | EAK100-01A-KIT | 1    |
| 35                  | Coil Spring                             | DAN022-01A     | 1    | 83      | Slider Plate                         | MAS084-01A     | 1    |
| 36                  | Rotor Cover                             | DAN087-10A     | 1    | 84      | Slider Plate Screw (3 pk)            | JAS085-01A-KIT | 1    |
| 37                  | Line Roller Screw (3 pk)                | CAN108-01A-KIT | 1    | 85      | Side Cover Assembly                  | MAS323-01A     | 1    |
| 38                  | Arm Lever                               | DAN007-10A     | 1    | 86A     | Side Cover Screw1 (3 pk)             | MAS163-01A-KIT | 1    |
| 39                  | Line Roller Collar                      | EAK102-01A     | 1    | 86B     | Side Cover Screw2 (3 pk)             | MAS057-01A-KIT | 1    |
| 40                  | Line Roller Bushing                     | EAK106-01A     | 2    | 87      | Drive Gear Seal                      | EAN265-01A     | 1    |
| 41                  | Line Roller                             | MAS004-01A     | 1    | 90      | Handle Arm Assembly                  | MAS318-01A     | 1    |
| 42                  | Bail Wire Assembly                      | MAS347-01A     | 1    | 91      | Handle Knob Bushing                  | CAN027-01A     | 2    |
| 43                  | Line Roller Washer_shorter              | EAK102-51A     | 1    | 92      | Handle Knob                          | CAN013-01A     | 1    |
| 45                  | Line Roller Washer_longer               | EAK102-52A     | 1    | 93      | Handle Knob Screw (3 pk)             | CAN123-01A-KIT | 1    |
| 47                  | Rotor Cover Screw (3 pk)                | DAN077-01A-KIT | 1    | 94      | Handle Knob Cap                      | CAN169-01A     | 1    |
| 48                  | Rotor Adjuster Washer                   | DAN065-01A     | 1    | 95X     | Dust Cap Assembly                    | DAN373-01A     | 1    |
| 50                  | Seal                                    | CAN252-01A     | 1    | 100     | Clicker Spring Washer                | EAK167-01A     | 1    |
| 53                  | Pinion Ball Bearing Holder Screw (3 pk) | MAS051-01A-KIT | 1    | 110     | Rear Cap                             | MAS250-01A     | 1    |
|                     |                                         |                |      | 111     | Rear Cap Screw (3 pk)                | CAN077-01A-KIT | 1    |