


**QUANTUM**  
MERIT™ MFL6000 Part List



| QUANTUM - Quick Kits |                               |             |      |
|----------------------|-------------------------------|-------------|------|
| KEY NO.              | DESCRIPTION                   | PART NUMBER | QTY. |
| 1X                   | DRAG KNOB ASSEMBLY            | EAN332-01A  | 1    |
| 4X                   | DRAG KIT                      | DAN380-01A  | 1    |
| 2                    | Retaining Ring                |             | 1    |
| 3                    | Metal D Washer (3 pk)         |             | 1    |
| 4                    | Carbon Friction Washer (3 pk) |             | 1    |
| 5X                   | SPOOL CLICKER&LINE CLIP KIT   | NAS303-01A  | 1    |
| 7                    | Screw (3 pk)                  |             | 1    |
| 8                    | Clicker Holder                |             | 1    |
| 9                    | Clicker                       |             | 1    |
| 11                   | Clicker Screw (3 pk)          |             | 1    |
| 12                   | Clicker Spring                |             | 1    |
| 100                  | Clicker Spring Washer         |             | 1    |
| 10X                  | SPOOL ASSEMBLY                | EAS421-01A  | 1    |
| 4X                   | Drag Kit                      |             | 1    |
| 10                   | Spool Sub Assembly            |             | 1    |
| 5X                   | Spool Click&Clip Kit          |             | 1    |
| 16X                  | SPOOL SUPPORT KIT             | EAS415-01A  | 1    |
| 15                   | Spool Metal Seal              |             | 1    |
| 16                   | Spool Adjust Washer           |             | 1    |
| 20                   | Main Shaft Assembly           |             | 1    |
| 35X                  | BAIL TRIP KIT                 | NAS319-01A  | 1    |
| 33                   | Cam                           |             | 1    |
| 34                   | Kick Lever                    |             | 1    |
| 35                   | Coil Spring                   |             | 1    |
| 90X                  | HANDLE ASSEMBLY               | NAS418-01A  | 1    |
| 90                   | Handle Arm Assembly           |             | 1    |
| 92X                  | Handle Knob Assembly          |             | 1    |
| 92X                  | HANDLE KNOB KIT               | EAN313-01A  | 1    |
| 91                   | Handle Knob Bushing           |             | 2    |
| 92                   | Handle Knob                   |             | 1    |
| 93                   | Handle Knob Screw (3 pk)      |             | 1    |
| 94                   | Handle Knob Cap               |             | 1    |
| 95X                  | DUST CAP ASSEMBLY             | DAN373-01A  | 1    |

| PART LIST -- MFL6000 |                                         |                |      |         |                                      |                |      |  |  |  |  |
|----------------------|-----------------------------------------|----------------|------|---------|--------------------------------------|----------------|------|--|--|--|--|
| KEY NO.              | DESCRIPTION                             | PART NUMBER    | QTY. | KEY NO. | DESCRIPTION                          | PART NUMBER    | QTY. |  |  |  |  |
| 1X                   | Drag Knob Assembly                      | EAN332-01A     | 1    | 70      | Body Assembly                        | EAS301-01A     | 1    |  |  |  |  |
| 2                    | Retaining Ring                          | EAK172-01A     | 1    | 71      | Side Cover Seal                      | EAS254-01A     | 1    |  |  |  |  |
| 3                    | Metal D Washer (3 pk)                   | DAN080-01A-KIT | 1    | 72      | Drive Gear Ball Bearing Seal         | EAN262-01A     | 2    |  |  |  |  |
| 3B                   | Rear Drag Metal E Washer(3pk)           | CAS081-01A-KIT | 1    | 73      | Drive Gear Ball Bearing Seal Plate   | MAS255-01A     | 2    |  |  |  |  |
| 4                    | Carbon Friction Washer (3 pk)           | DAN033-01A-KIT | 1    | 74      | Side Cover Ball Bearing Screw (3 pk) | EAK220-01A-KIT | 1    |  |  |  |  |
| 4B                   | Rear Drag Carbon Friction Washer (3 pk) | CAS033-01A-KIT | 1    | 75      | Drive Gear                           | DAS012-01A     | 1    |  |  |  |  |
| 7                    | Screw (3 pk)                            | EAK114-01A-KIT | 1    | 76      | Drive Gear Ball Bearing Screw (3 pk) | JAS220-01A-KIT | 1    |  |  |  |  |
| 8                    | Clicker Holder                          | EAK204-01A     | 1    | 77      | O/S Gear Washer                      | DAS158-01A     | 1    |  |  |  |  |
| 9                    | Clicker                                 | EAK103-01A     | 1    | 78      | O/S Gear                             | EAS053-01A     | 1    |  |  |  |  |
| 10                   | Spool Sub Assembly --Use 10X            |                |      | 79      | O/S Gear Screw (3 pk)                | JAS111-01A-KIT | 1    |  |  |  |  |
| 11                   | Clicker Screw (3 pk)                    | EAK246-01A-KIT | 1    | 80      | Slider                               | EAS025-01A     | 1    |  |  |  |  |
| 12                   | Clicker Spring                          | EAK068-01A     | 1    | 82      | Slider Holder Plate Screw (3 pk)     | DAS085-01A-KIT | 1    |  |  |  |  |
| 15                   | Spool Metal Seal                        | DAN251-01A     | 1    | 85      | Side Cover Assembly                  | EAS323-01A     | 1    |  |  |  |  |
| 16                   | Spool Adjust Washer                     | EAK030-01A     | 1    | 86A     | Side Cover Screw1 (3 pk)             | CAS057-02A-KIT | 1    |  |  |  |  |
| 20                   | Main Shaft Assembly                     | EAS315-01A     | 1    | 86B     | Side Cover Screw2 (3 pk)             | EAS057-01A-KIT | 1    |  |  |  |  |
| 22                   | Rotor Nut Retainer Screw (3 pk)         | EAK094-01A-KIT | 1    | 90      | Handle Arm Assembly                  | NAS318-01A     | 1    |  |  |  |  |
| 23                   | Rotor Nut Retainer                      | EAK118-01A     | 1    | 91      | Handle Knob Bushing                  | EAN027-01A     | 2    |  |  |  |  |
| 24                   | Rotor Nut Retainer Seal                 | DAN264-01A     | 1    | 91B     | O/S Gear Bushing                     | DAS027-01A     | 1    |  |  |  |  |
| 25                   | Rotor Nut Seal                          | DAN265-01A     | 1    | 92      | Handle Knob                          | EAN013-01A     | 1    |  |  |  |  |
| 26                   | Rotor Nut                               | EAK006-01A     | 1    | 93      | Handle Knob Screw (3 pk)             | CAN123-01A-KIT | 1    |  |  |  |  |
| 29                   | Bushing                                 | BAN259-01A     | 2    | 94      | Handle Knob Cap                      | EAN169-01A     | 1    |  |  |  |  |
| 30                   | Rotor                                   | EAN009-10A     | 1    | 95X     | Dust Cap Assembly                    | DAN373-01A     | 1    |  |  |  |  |
| 32                   | Arm Lever Screw (3 pk)                  | CAN225-01A-KIT | 1    | 100     | Clicker Spring Washer                | EAK167-01A     | 1    |  |  |  |  |
| 33                   | Cam                                     | DAN031-01A     | 1    | 115     | Rear Drag Washer                     | CAS033-02A     | 1    |  |  |  |  |
| 34                   | Kick Lever                              | EAN019-01A     | 1    | 116     | Rear Drag Cam                        | CAS060-01A     | 1    |  |  |  |  |
| 35                   | Coil Spring                             | DAN022-01A     | 1    | 117     | Rear Drag Coil Spring                | CAS043-01A     | 1    |  |  |  |  |
| 36                   | Rotor Cover                             | EAN087-10A     | 1    | 118     | Rear Drag Nut                        | CAS066-01A     | 1    |  |  |  |  |
| 37                   | Line Roller Screw (3 pk)                | CAN108-01A-KIT | 1    | 119     | Rear Drag Knob Seal                  | DAS164-01A     | 1    |  |  |  |  |
| 38                   | Arm Lever                               | EAN007-10A     | 1    | 120     | Rear Drag Knob Rubber Band           | DAS171-01A     | 1    |  |  |  |  |
| 39                   | Line Roller Collar                      | EAK102-01A     | 1    | 121     | Rear Drag Knob Clip                  | CAS070-01A     | 1    |  |  |  |  |
| 40                   | Line Roller Bushing                     | EAK016-01A     | 2    | 122     | Rear Drag Knob                       | DAS064-01A     | 1    |  |  |  |  |
| 41                   | Line Roller                             | EAN004-01A     | 1    | 123     | Rear Drag Lever R Screw A (3 pk)     | CAS135-02A-KIT | 1    |  |  |  |  |
| 42                   | Bail Wire Assembly                      | NAS347-01A     | 1    | 124     | Rear Drag Lever R Screw B (3 pk)     | CAS225-01A-KIT | 1    |  |  |  |  |
| 43                   | Line Roller Washer shorter              | EAK102-51A     | 1    | 125     | Rear Drag Lever R                    | DAS112-01A     | 1    |  |  |  |  |
| 45                   | Line Roller Washer longer               | EAK102-52A     | 1    | 126     | Rear Drag Pawl Spring                | CAS061-01A     | 1    |  |  |  |  |
| 47                   | Rotor Cover Screw (3 pk)                | DAN077-01A-KIT | 1    | 127     | Rear Drag Pawl                       | EAS063-01A     | 1    |  |  |  |  |
| 49                   | Silent Ring                             | EAK059-01A     | 1    | 128     | Rear Drag Stop Nut                   | DAS066-01A     | 1    |  |  |  |  |
| 50                   | Seal                                    | EAN252-01A     | 1    | 129     | Slider Holder Plate                  | DAS084-01A     | 1    |  |  |  |  |
| 51                   | Silent Ring Sleeve                      | EAK078-01A     | 1    | 130     | Rear Drag Lever Spring               | EAS216-01A     | 1    |  |  |  |  |
| 52                   | Silent Spring                           | EAK069-01A     | 1    | 131     | Rear Drag Lever O-Ring               | CAS164-01A     | 2    |  |  |  |  |
| 53                   | Pinion Ball Bearing Holder Screw (3 pk) | MAS051-01A-KIT | 1    | 132     | Rear Drag Lever Shaft                | DAS114-01A     | 1    |  |  |  |  |
| 54                   | Pinion Ball Bearing Holder              | EAS122-01A     | 1    | 134     | Trip Link Screw(3pk)                 | CAS163-01A-KIT | 1    |  |  |  |  |
| 55                   | Pinion Ball Bearing Holder Seal         | EAS263-01A     | 1    | 135     | Trip Link                            | CAS096-01A     | 1    |  |  |  |  |
| 56                   | Pinion Ball Bearing                     | CP058-05A      | 4    | 136     | Trip Link Pawl                       | EAS089-01A     | 1    |  |  |  |  |
| 57                   | Pinion Ball Bearing Retainer            | EAS040-01A     | 1    | 137     | Trip Link Bushing                    | EAS204-01A     | 1    |  |  |  |  |
| 58                   | Pinion Bushing Top                      | DAN028-01A     | 1    | 138     | Trip Link Spring                     | CAS117-01A     | 1    |  |  |  |  |
| 59                   | Clutch Unit                             | DAS463-01A     | 1    | 139     | Rear Drag Cam Clicker                | CAS103-01A     | 1    |  |  |  |  |
| 60                   | Pinion                                  | EAS011-01A     | 1    | 140     | Rear Drag Knob Clicker Spring        | CAS083-01A     | 1    |  |  |  |  |
| 62                   | Rotor Brake                             | EAN145-01A     | 1    | 141     | Rear Drag Knob Clicker               | CAS149-01A     | 1    |  |  |  |  |
| 63                   | Rotor Brake Screw (3 pk)                | MAS135-01A-KIT | 1    | 142     | Rear Drag Lever L                    | DAS113-01A     | 1    |  |  |  |  |
| 66                   | Anti-Reverse Pawl Spring Space          | EAK091-01A     | 1    | 143     | Drive Gear Pawl Lever Spring         | DAS069-01A     | 1    |  |  |  |  |
| 67                   | Anti-Reverse Pawl                       | EAK090-01A     | 1    | 144     | Drive Gear Pawl Lever                | DAS074-01A     | 1    |  |  |  |  |
| 68                   | Anti-Reverse Pawl Spring                | EAK089-01A     | 1    | 145     | Drive Gear Pawl Lever E-clip         | CAS120-01A     | 1    |  |  |  |  |
| 69                   | E-clip                                  | QW120-01A      | 1    | 146     | Drive Gear Adjust Washer             | DAN065-01A     | 1    |  |  |  |  |